

**GENERAL DESCRIPTION**

LpH III se Phenolic Disinfectant is an acidic germicidal detergent designed to be an effective one-step disinfectant cleaner when diluted using one fluid ounce per gallon (0.8% v/v or 1:128) with soft or hard water to 400 ppm hardness (Association of Analytical Communities [AOAC] hard water) and in the presence of 5% blood serum.

LpH III se phenolic disinfectant is intended for use on washable hard, non-porous environmental surfaces such as floors, walls, counters, tools, carts and other equipment in pharmaceutical, medical device and cosmetic manufacturing facilities.

Use the use-dilution for cleaning, disinfecting and deodorizing stainless or galvanized steel and chrome, glazed porcelain, plastics, glass, glazed tile, washable painted or varnished surfaces, sealed concrete, as well as resilient vinyl, linoleum, rubber and terrazzo.

**FEATURES**

Advanced phenolic formula that kills a range of gram positive, gram negative and acid fast bacilli. Both fungicidal and virucidal activity, including against Human Immunodeficiency Virus (HIV-1)

Hard water (400 ppm as CaCO<sub>3</sub>) effective

5% organic soil (serum) effective

**BENEFITS**

Broad spectrum germicidal activity, including TB, bacteria, and Human Immunodeficiency Virus (HIV-1)

Disinfection verified in most tap waters

Proven effective in simulated use conditions

**PHYSICAL PROPERTIES**

Form.....	Clear, light straw to dark amber
Odor .....	Mild and characteristic
Specific Gravity (25°C [77°F]) .....	1.114 typical
Typical pH (Undiluted).....	Approx. 0.25
Typical pH (1:128 dilution).....	2.1 typical

**BACTERICIDAL PROPERTIES**

The official test for determining the germicidal efficacy of a one-step cleaner disinfectant is the Use Dilution Method as stated in the AOAC Methods of Analysis. LpH III se phenolic disinfectant diluted 1:128 in 400 ppm (CaCO<sub>3</sub>) hard water is effective against the following microorganisms in the presence of 5% blood serum, 10 minutes at 20°C.

<i>Acinetobacter baumannii</i> ,	ATCC19606
<i>Enterobacter cloacae</i> ,	ATCC 13047
<i>Escherichia coli</i> ,	ATCC 25922
<i>Micrococcus luteus</i>	ATCC 7468
<i>Serratia marcescens</i> ,	ATCC 14756
<i>Staphylococcus aureus</i>	ATCC 6538
<i>Pseudomonas aeruginosa</i>	ATCC 15442

**FUNGICIDAL PROPERTIES**

The official test for determining the fungicidal efficacy of a one-step cleaner disinfectant is the AOAC Fungicidal Method as described in the AOAC Methods of Analysis, and modified as required by EPA regulations. LpH III se phenolic disinfectant diluted 1:128 in 400 ppm (as CaCO<sub>3</sub>) hard water is effective against *Trichophyton interdigitales* (ATCC 9533) in the presence of 5% blood serum, 10 minutes at 20°C.

## TUBERCULOCIDAL PROPERTIES

---

LpH III se Phenolic Disinfectant passes the AOAC Tuberculocidal Test Method 965.12 [*Mycobacterium tuberculosis var. bovis* {BCG}] when diluted 1:128 with 400 ppm AOAC hard water in the presence of 5% organic soil (serum), 10 minutes at 20°C.

## VIRUCIDAL PROPERTIES

---

When using the EPA Proposed Method (ASTM 1053-11), LpH III se phenolic disinfectant is effective against the following viruses at a 1:128 dilution in 400 ppm hard water and 5% serum in 10 minutes at 19-21°C.

- Human Immunodeficiency Virus (HIV-1)
- Influenza A2 (H2N2) A/2/Japan/305/57
- Adenovirus Type 2 (ATCC VR 846)
- Avian Influenza Virus (H9N2)

## DIRECTIONS FOR USE

---

It is a violation of Federal Law to use this product in a manner inconsistent with its labeling.

### **Cleaning and disinfecting washable, hard, non-porous surfaces:**

To make a solution, add one fluid ounce (30 cc) of product per each pre-measured gallon of water used (0.8% v/v) and gently mix until solution is uniform. Always add this product (detergent) to pre-measured water. Gently mix for a uniform solution. Apply solution with a cloth, sponge, mop, brush or coarse spray using normal cleaning methods. Allow treated surfaces to soak for 10 minutes, then remove excess solution with a wrung-out applicator. Prepare a fresh dilution at least daily or as solution becomes dirty, discard and replace with a fresh one. Before cleaning begins, always sweep or dust mop area to be cleaned thoroughly, removing any gross filth. This is a complete product. Do not add or dilute with other chemicals. If frozen, thaw and re-mix before use. Use only as directed.

### **Kills HIV on precleaned environmental surfaces/objects previously soiled with blood and bodily fluids**

in settings in which there is an expected likelihood of soiling of inanimate surfaces/objects with blood or bodily fluids, and which the surfaces/objects likely to be soiled with blood or bodily fluids can be associated with potential for transmission of human immunodeficiency virus Type HIV-1 (associated with AIDS).

### **Special Instructions for cleaning and decontamination against HIV-1 (Human Immunodeficiency Virus or AIDS virus) on surfaces/objects soiled with blood/bodily fluids:**

**Personal Protection:** Wear appropriate barrier protection such as latex gloves, gowns, masks and eye coverings.

**Cleaning Procedure:** Blood and other bodily fluids must be thoroughly cleaned from surfaces and objects before application of a 1:128 use-solution (one ounce per one gallon). Prepare and apply solution as directed in paragraph above.

**Contact Time:** HIV-1 virus is inactivated in 10 minutes.

**Infectious Materials Disposal:** Blood and other bodily fluids should be autoclaved and disposed of according to local regulations for infectious disposal.

## STORAGE AND DISPOSAL

---

Do not contaminate food, feed or water by storage or disposal.

**Pesticide Storage:** Do not store near heat or open flame. If frozen, thaw and remix before use.

**Pesticide Disposal:** Pesticide wastes are actually hazardous. Improper disposal of excess pesticide, spray mixture or rinsate is a violation of Federal Law. If these wastes cannot be disposed of by use according to the label instructions, contact your state Pesticide or Environmental Control Agency, or the Hazardous Waste representative at the nearest EPA Regional Office for guidance.

**Container Disposal: (For Packet:)** Nonrefillable container. Do not reuse or refill this container. Offer for recycling, if available or dispose in sanitary landfill or by other procedures approved by state and local authorities.

**(For  $\leq 5$  gal:)** Nonrefillable container. Do not reuse or refill this container. Offer for recycling, if available or dispose in sanitary landfill or by other procedures approved by state and local authorities. Clean container promptly after emptying. Triple rinse as follows: Empty the remaining contents into application equipment or a mix tank and drain for 10 seconds after the flow begins to drip. Fill the container 1/4 full with water and recap. Shake for 10 seconds. Pour rinsate into application equipment or a mix tank to store rinsate for later use or disposal. Drain for 10 seconds after the flow begins to drip. Repeat this procedure two more times.

**(For  $>5$  gal:)** Nonrefillable container. Do not reuse or refill this container. Offer for recycling, if available or dispose in sanitary landfill or by other procedures approved by state and local authorities. Clean container promptly after emptying. Triple rinse as follows: Empty the remaining contents into application equipment or a mix tank. Fill the container 1/4 full with water. Replace and tighten closures. Tip container on its side and roll it back and forth, ensuring at least one complete revolution, for 30 seconds. Stand the container on its end and tip it back and forth several times. Turn the container over onto its other end and tip it back and forth several times. Empty the rinsate into application equipment or a mix tank or store rinsate for later use or disposal. Repeat this procedure two more times.

## SERVICE

---

### Sales

Service is one of the most important ways to verify consistent quality of the facility's performance and operation. A tailored service program by STERIS provides effective, trouble-free operations.

### Technical

STERIS is pleased to provide a completely staffed and equipped technical service laboratory capable of performing needed tests and providing both telephone and on-site assistance when needed. More details on how this service can benefit a facility's particular situation can be provided upon request.

## PRECAUTIONS

---

Information concerning human and environmental exposure may be reviewed on the Safety Data Sheet (SDS) for this product. For additional information regarding incidents involving human and environmental exposure, call +1-314-535-1395.

---

**For further information, please contact:**



STERIS Corporation  
5960 Heisley Road  
Mentor, OH 44060-1834 • USA  
440-354-2600 • 800-548-4873  
[www.STERISLifeSciences.com](http://www.STERISLifeSciences.com)