



INTRODUCING NEW HG & VT SERIES MASTER® & VARITEMP® HEAT GUNS

INDUSTRY'S MOST RUGGED, RELIABLE HEAT TOOLS JUST GOT BETTER

- Upgraded long-life universal motor delivers 2X PLUS run life
- High 27 CFM airflow gets tough jobs done faster
- New quick-change plug-in heating element with even airflow over element for maximum heating efficiency
- Optimized design for improved serviceability
- Redesigned ergonomic soft grip handle maximizes user comfort
- Sturdy die cast aluminum housing
- Fixed air intake provides temperature consistency, improving process control
- Hot-Cool-Off Rocker Switch
- Non-slip, reinforced stand offers stable 90-degree adjustability
- New variable temperature dial for VT Models offers lockable temperature capability
- Full selection of replacement part kits for easy serviceability
- Designed and assembled by Master Appliance Corp., Racine, WI. USA



Master HG and VT Heat Gun Specifications

Specifications

- **Dimensions:** 10" L x 5.25" W x 9.5" H
- **Nozzle O.D.:** 1½"
- **Nozzle Shield O.D.:** 1¾"
- **Cord Length:** 6ft, 3-wire grounded
- **Average Air Velocity:** 3400 FPM at ambient
- **Average Air Volume:** 27 CFM at ambient
- **Tool Weight:** 3.7 lbs

Master Heat Gun®

Model No.	Temperature		Voltage	Amps	Watts	Replacement Element
	°F	°C				
HG-201D	400	204	120	5	600	30087
HG-301D	800	426	120	12	1440	30085
HG-501D	1200	649	120	14.5	1740	30083
HG-801D*	1400	760	120	18.5	2220	30082
HG-202D**	400	204	220	3	660	30088
HG-302D**	800	426	220	6	1320	30086
HG-502D**	1200	649	220	9	1980	30084

* Equipped with NEMA 5-20P Plug, requires 20A outlet

** Equipped with 6-15P plug, requires 220V outlet

Optional Momentary Contact Switch for 120V Models: Unit shuts off when switch is released. To order add "-00-MC" suffix to model number. Example: HG-501D-00-MC

Master Varitemp® Heat Gun

Model No.	Temperature		Voltage	Amps	Watts	Replacement Element
	°F	°C				
VT-751D	100-1200	38-649	120	14.5	1740	30083
VT-752D**	100-1200	38-649	220	9	1980	30084

** Equipped with 6-15P plug, requires 220V outlet

Add Versatility to your HG & VT Model Heat Guns — Heat Gun Kits available for all 120V models. Kits include a Master Heat Gun or Varitemp Heat Gun, A-160-HG shrink attachment, 51543 spreader attachment and a 51544 reducer attachment packed in a rugged plastic storage case. To order add "-00-K" suffix to model number. Example: HG-501D-00-K

Attachments



Model No.	51309 Pinpoint	30202 Solder Preform	51542 Glass Protector	A-160-HG A-170-HG Shrink Tube	51543 Spreader	51544 7/8 Reducer
HG-801D			•	•	•	•
HG-201D	•	•	•	•	•	•
HG-301D	•	•	•	•	•	•
HG-501D	•	•	•	•	•	•
HG-202D	•	•	•	•	•	•
HG-302D	•	•	•	•	•	•
HG-502D	•	•	•	•	•	•
VT-751D	•	•	•	•	•	•
VT-752D	•	•	•	•	•	•

Master Heat Gun® Replacement Parts (HG/VT Models)

Part No.	Description
35153	Blower Wheel
30070	Stand Kit
30073	Motor 120V
30074	Motor 220-240V
30075	Switch Bezel Kit (3 pos)
30076	Switch Bezel Kit (MC)
30077	Nozzle Shield Kit
30078	Grille Kit
30079	Cordset Kit 120V 15amp (-00)
30080	Cordset Kit 120V 20amp (-01)
30081	Cordset Kit 220V UL/CUL (-02)
30082	Element Kit, HG-801D (120V)
30083	Element Kit, HG-501D & VT-751D (120V)
30084	Element Kit, HG-502D & VT-752D (220V)
30085	Element Kit, HG-301D (120V)
30086	Element Kit, HG-302D (220V)
30087	Element Kit, HG-201D (120V)
30088	Element Kit, HG-202D (220V)
30089	Element Connector
30090	Element Connector 20amp
30091	Handle Kit
30092	VT-Knob Kit
30093	Circuit Board Kit VT-751D (120V)
30094	Circuit Board Kit VT-752D (220V)
30100	HG & VT Storage Case

Please visit www.masterappliance.com or contact Master Appliance Corp at **262-633-7791** for more information.

For Master Appliance products contact:

Master Appliance Corp. ▪ 2420 18th St. ▪ Racine, WI 53403 ▪ US & Canada 800.558.9413 ▪ International 262.633.7791
Fax 262.633.9745 ▪ MasterAppliance.com ▪ E-mail: Sales@MasterAppliance.com

As with all electrical equipment and tools, for your safety, read the instruction manual before using. All information including illustrations, is believed to be reliable. Users, however, should independently evaluate the suitability of this product for their application. The only obligations of Master Appliance are those in the Standard Terms and Conditions of Sale for this product. In no case will Master Appliance be liable for any incidental indirect, or consequential damages arising from the sale, resale, use or misuse of this product. FORM# 58109