

HyFlex®

ADVANCED MECHANICAL PROTECTION

11-537

3/4 Dipped Light Duty Gloves with
INTERCEPT™ Technology and
ANSELL GRIP Technology™



Light Duty



Cut-Protection

Exceptional grip performance and 3/4 dip protection in a comfortable ultralight weight cut resistant glove



The 11-537 epitomizes the convergence of protection and performance. It features an 18G ultralight weight liner with INTERCEPT™ Technology yarns that provides EN Cut Level 3 protection. The liner also features ZONZ™ Comfort Fit Technology for breathability and ergonomic movement. The 3/4 dipped coating and the FORTIX™ Technology formulation provide enhanced abrasion resistance and grip. To provide all four advanced performance technologies, including EN Level 3 cut protection, in a comfortable, flexible ultralight weight style, is a game changer for applications where workers have traditionally guarded against cut risks with heavier styles that limit their dexterity and breathability.

Industries

- Aerospace
- Automotive
- Machinery and Equipment
- Metal Fabrication

Applications

- Assembly of small sharp parts
- Handling small sharp metal parts
- Light duty stamping
- Maintenance

HyFlex®

ADVANCED MECHANICAL PROTECTION

11-537

3/4 Dipped Light Duty Gloves with INTERCEPT™ Technology and ANSELL GRIP Technology™

Performance Profile

Best-in-class Cut Resistance Technology

New-to-the-world INTERCEPT™ Technology yarn has been designed to exceed industry standards. This Ansell proprietary technology offers best-in-class cut protection and increased comfort with dexterity.

3/4 Dip Geometry

Extended coating on back of hand for comprehensive protection against snags and mechanical aggression.

Enhanced Grip Performance

ANSELL GRIP Technology™ is a coating treatment that minimizes the force required to grip oily or wet tools or materials, reducing hand and arm fatigue and improving control, safety and productivity.

Advanced Abrasion Protection

FORTIX™ Technology applies a thin, resilient and breathable nitrile foam coating, which extends gloves' working life and improves comfort in abrasive applications.

Key Features

Barehand-like Tactility

Ultralight weight glove that offers unparalleled dexterity and refined mobility.

Comfort Fit Technology

ZONZ™ Technology uses selected yarns and varying stitch designs to tailor overall glove fit to enhance hand movement for higher dexterity and reduced fatigue.

Silicone-free

Silicone free design is paint and finish process friendly.

Dirt-Masking Color

Dirt masking palm for longer wear times.

Performance Standards



Featured Technologies

INTERCEPT™
Cut Resistance Technology

ANSELL GRIP™
Ansell Grip Technology™

FORTIX™
Abrasion Resistance Technology

ZONZ™
Comfort Fit Technology

Specifications

STYLE	DESCRIPTION	GAUGE	LENGTH	COLOR	PACKAGE
11-537	Type: 3/4 dipped Coating material: silicon free Nitrile Liner material: Seamless synthetic blend with INTERCEPT™ Technology yarn Cuff style: knit wrist	18	220-270 mm	Grey liner with dark grey palm coating	12 pairs/bag, 12 bags/carton

SIZE	ASPN NA/LAC	ORACLE NA/LAC	ASPN EMEA/APAC	ORACLE EMEA/APAC
6	810427	11537060	810445	11537060
7	810428	11537070	810447	11537070
8	810429	11537080	810448	11537080
9	810430	11537090	810449	11537090
10	810431	11537100	810450	11537100
11	810432	11537110	810452	11537110

* & ™ are trademarks owned by Ansell Limited or one of its affiliates, © 2015 Ansell Limited. All Rights Reserved.

Neither this document nor any other statement made herein by or on behalf of Ansell should be construed as a warranty of merchantability or that any Ansell product is fit for a particular purpose. Ansell assumes no responsibility for the suitability or adequacy of an end user's selection of gloves for a specific application.

Europe

Ansell Healthcare Europe NV
Riverside Business Park
Blvd International, 55
1070 Brussels, Belgium
+32 2 528 74 00
+32 2 528 74 01

Hong Kong

Ansell (Hong Kong) Limited
Unit 3102-3103, 31/F
Manhattan Place
23 Wang Tai Road
Kowloon Bay, Hong Kong
+852 2185 0600
+852 2856 2155

United States

Ansell Protective Products Inc.
111 Wood Avenue South
Suite 210
Iselin, NJ 08830, USA
+1 800 800 0444
+1 800 800 0445

Latin America

Ansell Brazil Ltda.
Rua das Figueiras, 474 - 4º Andar
Bairro Jardim
SP 09080-300 Santo André
Brazil
CNPJ: 03.496.778/0001-21
+55 11 3356 3100

Australia

Ansell Limited
Level 3, 678 Victoria Street,
Richmond, Vic, 3121
Australia
+61 1800 337 041
+61 1800 803 578

Russia

Анселл РУС
123610 Россия, Москва
Краснопресненская
Наб. 12, п.3, оф. 1304А
Тел. +7 495 258 13 16

Ansell