

Product Datasheet

ES6011.CR.BG Product code:

Product type: **High Precision Pliers**

Made in: Switzerland

Description: The 6011 is a high precision plier belonging to the flat nose plier family. The short jaw

> length increases the strength of the hold. The smooth surface on the jaw prevents scratches while holding. The 6011 is equipped with an ESD Ergo-tek slim handle which allows an excellent grip, suitable to environments and to components susceptible to

electrostatic discharge. The jaws are hardened to 45HRC hardness.

Head description: Flat Nose, Smooth Jaws

Body material: High carbon-chromium low alloy steel (100Cr6)

ESD safe - Thermoplastic Elastomer TPE + Polypropylen compound PP Handle coating:

Picture:





Dimensions: OAL 130 mm – 5.118 inch

Width 60 mm - 2.362 inch

Height 18 mm - 0.709 inch

