

HyFlex®

ADVANCED MECHANICAL PROTECTION

11-724

Palm Dipped Medium Duty, 13 Gauge
Gloves with INTERCEPT™ Technology



Medium Duty



Cut-Protection

Excellent Flexibility and Fit with Optimal Cut Protection



The 11-724 features a 13G lightweight liner with INTERCEPT™ Technology yarns that provides EN Cut Level 3 (ANSI Level 2) protection. The liner also features an optimized Lycra® content that is soft and cool on the skin for all-day comfort. The palm dipped polyurethane (PU) coating provides enhanced grip in light oil environments for secure handling and offers EN Abrasion Level 4 (ANSI Level 6) for extended glove life. The PU coating is also silicone-free to protect the quality of industrial finishing processes

Industries

- Aerospace
- Automotive
- Transport
- White Goods

Applications

- Assembly of metal parts
- Light Metal presses
- Maintenance
- Moulding
- Primary Assembly

Performance Profile

Best-in-class Cut Resistance Technology

New-to-the-world INTERCEPT™ Technology yarn has been tested to perform at or exceed industry standards. This Ansell proprietary technology offers best-in-class cut protection and increased comfort and dexterity.

Palm Dip Geometry

The palm coating design improves worker grip, extends glove life in abrasive conditions and allows the back-of-hand to breath.

Key Features

Silicone-free PU Coating

More process friendly in use when metal parts will be painted.

Dirt-Masking Coating Color

Coating hides dirt in environments with dirt exposure.

Long-life Coating

Resilient coating resists abrasions and extends glove life.

Performance Standards



4342
EN 388



CUT



ABRASION



Featured Technologies



INTERCEPT™
Cut Resistance Technology

Specifications

STYLE	DESCRIPTION	GAUGE	LENGTH	COLOR	PACKAGE
11-724	Type: palm dipped Coating material: silicon-free polyurethane Liner material: Seamless liner with INTERCEPT™ Technology yarn Cuff style: knit wrist	13	208-261 mm*	White liner with black coating	12 pairs/bag, 12 bags/carton

* tolerance of ±8 mm

SIZE	ASPN NA/LAC	ORACLE NA/LAC	ASPN EMEA/APAC	ORACLE EMEA/APAC
6	163830	163830	800957	123872
7	163831	163831	800958	123873
8	163832	163832	800959	123874
9	163833	163833	800960	123875
10	163834	163834	800961	123876
11	163835	163835	800962	123877

* & ™ are trademarks owned by Ansell Limited or one of its affiliates, © 2015 Ansell Limited. All Rights Reserved.
Lycra® is a registered trademark of INVISTA.

Neither this document nor any other statement made herein by or on behalf of Ansell should be construed as a warranty of merchantability or that any Ansell product is fit for a particular purpose. Ansell assumes no responsibility for the suitability or adequacy of an end user's selection of gloves for a specific application.

Europe

Ansell Healthcare Europe NV
Riverside Business Park
Blvd International, 55
1070 Brussels, Belgium
+32 2 528 74 00
+32 2 528 74 01

Hong Kong

Ansell (Hong Kong) Limited
Unit 3102-3103, 31/F
Manhattan Place
23 Wang Tai Road
Kowloon Bay, Hong Kong
+852 2185 0600
+852 2856 2155

United States

Ansell Protective Products Inc.
111 Wood Avenue South
Suite 210
Iselin, NJ 08830, USA
+1 800 800 0444
+1 800 800 0445

Latin America

Ansell Brazil Ltda.
Rua das Figueiras, 474 - 4º Andar
Bairro Jardim
SP 09080-300 Santo André
Brazil
CNPJ: 03.496.778/0001-21
+55 11 3356 3100

Australia

Ansell Limited
Level 3, 678 Victoria Street,
Richmond, Vic, 3121
Australia
+61 1800 337 041
+61 1800 803 578

Russia

Анселл РУС
123610 Россия, Москва
Краснопресненская
Наб. 12, п.3, оф. 1304А
Тел. +7 495 258 13 16