



24" General Purpose Refrigerated Drawers

Model # MS24RDS**



Drawer-front mounted temperature display and user interface

Standard Features

- 2 extra-large, full-extensions drawers made of easy-to-sanitize and stain-resistant stainless steel
- Insulated thermal-efficient cabinet and drawer fronts ensures optimum efficiency and preservation
- Easy-to-grab full-width handles
- Cam-assisted drawer-close system to reduce "drawer-ajar" events
- Front vented through the toe space grill for true built-in installations
- 1" diameter probe port in rear cabinet wall (standard)
- Bright energy efficient white LED interior lighting for easy content viewing
- Extra-long, jacketed commercial power cord with hospital grade plug to meet stringent hospital and clinical use standards
- CSA Approved and warrantied for commercial use
- Recommended ambient temperature 18.3°C to 32.2°C (65°F to 90°F)
- One lock secures both drawers
- 4 leveling legs for up to 1" height adjustment




Full extension stainless steel drawers

Reliable Temperature Stability & Energy Efficiency

- Advanced forced air evaporator system design with optimized interior cooling air distribution
- Powerful compressor for fast pull-down time and temperature recovery after door opening or content loading
- New energy efficient drawer front gasket system seals in the cold, reducing energy consumption
- Automatic defrost without supplemental heat

MicroSentry™ II Temperature Control

- Drawer-front mounted control for easy access and monitoring
- Accurate electronic temperature control of contents within $\pm 2^{\circ}\text{C}$ of set point.
- Large, easy-to-read digital temperature display with resolution to 0.1°C
- User-selectable temperature set point between +2° and +8°C, factory preset to +4°C
- User-selectable high and low temperature alarm values
- User selectable alarm delay time period
- Visual and audible alarms for over temperature, under temperature, and "drawer-ajar" events
- Alarm silence and automatic ring back function
- Keypad lock-out to prevent unintended control inputs
- Basic high and low temperature logging with reset capability
- Visual diagnostic error codes



Storage Configuration

(2) extra-deep, full-extension drawers

Product Dimensions



23 ⁷/₈" W x 33 ³/₄" minimum H x 23 ²³/₃₂" D
(excluding door handle)

Finish/Drawer Options



White Cabinet / Stainless Steel Drawers

| Cabinet Dimensions | |
|--------------------|---|
| "D" | 23 ⁷ / ₈ " (60.7 cm) |
| "E" | 33 ³ / ₄ " to 34 ³ / ₄ " (85.7 to 88.3 cm) |
| "F" | 23 ²³ / ₃₂ " (60.2 cm) |
| "G" | 26 ⁷ / ₃₂ " (66.6 cm) |
| "H" | 39 ⁵ / ₃₂ " (99.5 cm) |



Ordering Details

White Cabinet and Stainless
Steel Drawers with Lock

MS24RDS4NS



| | |
|------------------------|----------------------------------|
| Width | 23 ⁷ / ₈ " |
| Interior Drawer Finish | Stainless Steel |
| Capacity | 4.7 Cubic Feet 133 Liters |
| Shelving System | 2 Drawers |
| Drawer Fronts | White |
| Interior Lighting | 2 LED Pods |
| Toe Grill Finish | Black |
| Drawer | Cam-assisted self close |

| | |
|-------------------------|------------------------------|
| Handle | Full Width |
| Control Type | MicroSentry™ II |
| Lock | Yes |
| Temperature Range | 36°F to 46°F (2°C to 8°C) |
| Electrical Requirements | 120V / 60Hz / 15A |
| Length of Power Cord | 5' |

| | |
|----------------------------------|--|
| Product Dimensions | 23 ⁷ / ₈ " W x 33 ³ / ₄ " H x 23 ²³ / ₃₂ " D |
| Depth to Front of Drawer | 23 ²³ / ₃₂ " |
| Depth to Handle | 26 ⁷ / ₃₂ " |
| Depth with drawer fully extended | 39 ⁵ / ₃₂ " |
| Shipping Weight | 135 lbs |
| Finishes | White/Stainless Steel |