

Product Datasheet

Product code: ES5341.CR.BG

Product type: High Precision Cutters

Made in: Switzerland

Description: The 5341 is a high precision cutter belonging to the small tapered cutter family. This type

of geometry and head dimensions offer an advantage to access small areas. The flush cutting edge is suitable to perform clean cuts with some tolerances. The 5341 is equipped with an ESD Ergo-tek slim handle which allows an excellent grip, suitable to environments and to components susceptible to electrostatic discharge. The blades are hardened to

67HRC hardness.

Head description: Small Tapered

Cutting edges: Flush

Cutting capacity: soft wire 0.1-1.2 mm (38-17 AWG)

Body material: High carbon-chromium low alloy steel (100Cr6)

Handle coating: ESD safe - Thermoplastic Elastomer TPE + Polypropylen compound PP

Picture:





Dimensions: OAL 120 mm – 4.724 inch

Width 60 mm - 2.362 inchHeight 18 mm - 0.709 inch

