

## Product Datasheet

**Product code:** ES5342.CR.BG

**Product type:** High Precision Cutters

**Made in:** Switzerland

**Description:** The 5342 is a high precision cutter belonging to the small tapered cutter family. This type of geometry and head dimensions offer an advantage to access small areas. The full-flush cutting edge is suitable to perform very clean cuts on small size material. The 5342 is equipped with an ESD Ergo-tek slim handle which allows an excellent grip, suitable to environments and to components susceptible to electrostatic discharge. The blades are hardened to 67HRC hardness.

**Head description:** Small Tapered

**Cutting edges:** Full-Flush

**Cutting capacity:** soft wire 0.1-1.0 mm ( 38-18 AWG)

**Body material:** High carbon-chromium low alloy steel (100Cr6)

**Handle coating:** ESD safe - Thermoplastic Elastomer TPE + Polypropylen compound PP

**Picture:**



**Dimensions:**  
 OAL 120 mm – 4.724 inch  
 Width 60 mm – 2.362 inch  
 Height 18 mm – 0.709 inch

