



Medium Duty



Cut-Protection

Protection with Comfort and Mobility



The 11-727 features a 15G lightweight liner with INTERCEPT yarns that provide EN Cut Level 3 protection. The thin, ergonomic liner also features an optimized lycra content that is soft and cool on the skin for all-day comfort. The palm-dipped polyurethane (PU) coating provides enhanced grip in light oil environments for secure handling and offers EN Abrasion Level 4 for extended glove life. The PU coating is also silicone-free to protect the quality of industrial finishing processes.

Industries

- Automotive & Automotive OEM
- Electrical machinery / Power tools
- Fabricated metal parts
- Packaging
- White goods / Durable goods

Applications

- Assembling metal parts and components
- Assembling white goods
- Cutting of small dry or lightly oiled parts and maintenance
- General maintenance
- Glass manufacturing
- Handling of sharp-edged objects
- Metal fabrication
- Paint Shop friendly, silicone free PU coating
- Plastics injection and moulding
- Pre-assembling

Performance Profile

Best-in-class Cut Resistance Technology

New-to-the-world INTERCEPT™ cut resistance yarn has been tested to perform at or exceed industry standards. This Ansell proprietary technology offers best-in-class cut protection and increased comfort and dexterity.

Palm Dip Geometry

The palm coating design improves worker grip, extends glove life in abrasive conditions and allows the back-of-hand to breathe.

Key Features

Dirt-Masking Coating Color

Coating hides dirt in environments with dirt exposure.

Long-life Coating

Resilient coating resists abrasions and extends glove life.

Performance Standards



Featured Technologies



Specifications

STYLE	DESCRIPTION	GAUGE	SIZES	LENGTH	COLOR	PACKAGE
11-727	Type: palm dipped Coating material: silicon-free polyurethane Liner material: Seamless Plaited liner with INTERCEPT™ technology yarn Cuff style: knitted wrist	15	6 - 11	200-255 mm	Grey liner with black coating	12 pairs/bag, 12 bags/carton

* & ™ are trademarks owned by Ansell Limited or one of its affiliates, © 2015 Ansell Limited. All Rights Reserved.

Neither this document nor any other statement made herein by or on behalf of Ansell should be construed as a warranty of merchantability or that any Ansell product is fit for a particular purpose. Ansell assumes no responsibility for the suitability or adequacy of an end user's selection of gloves for a specific application.

Australia

Ansell Limited
 Level 3, 678 Victoria Street,
 Richmond, Vic, 3121
 Australia
 +61 1800 337 041
 +61 1800 803 578

Europe

Ansell Healthcare Europe NV
 Riverside Business Park
 Blvd International, 55
 1070 Brussels, Belgium
 +32 2 528 74 00
 +32 2 528 74 01

United States

Ansell Protective Products Inc.
 111 Wood Avenue South
 Suite 210
 Iselin, NJ 08830, USA
 +1 800 800 0444
 +1 800 800 0445

Hong Kong

Ansell (Hong Kong) Limited
 Unit 3102-3103, 31/F
 Manhattan Place
 23 Wang Tai Road
 Kowloon Bay, Hong Kong
 +852 2185 0600
 +852 2856 2155

Latin America

Ansell Brazil Ltda.
 Rua das Figueiras, 474 - 4º Andar
 Bairro Jardim
 SP 09080-300 Santo André
 Brazil
 CNPJ: 03.496.778/0001-21
 +55 11 3356 3100

Russia

Анселл РУС
 123610 Россия, Москва
 Краснопресненская
 Наб. 12, п.3, оф. 1304А
 Тел. +7 495 258 13 16