

HyFlex®

ADVANCED MECHANICAL PROTECTION

11-644

Medium Duty Gloves with
INTERCEPT™ Technology and
an Ergonomic Design



Medium Duty



Cut-Protection

Safety, durability and comfort combined



No other glove offers the dynamic mix of protection, durability and comfort of the HyFlex® 11-644 glove. The ANSI Level 2 cut protection and lightweight ergonomic fit strike the perfect balance of protection and precision when working with small, sharp parts.

The HyFlex® 11-644 glove with INTERCEPT™ Cut Resistance Technology is an effective way to decrease injury expenses without reducing productivity or quality. That's because it combines superior cut protection, abrasion resistance, grip, tactility and dexterity in a comfortable glove your workers are more likely to wear.

Industries

- Aerospace
- Automotive
- Construction
- Electronics & Electrical
- Glass Production
- Metal Fabrication
- Paper Manufacturing
- Plastic & Rubber Manufacturing
- Public Utilities
- Tier One
- Transport
- White/Durable Goods

Applications

- Final & sub-assembly areas when handling metal components
- Forming, machining & bending small parts
- Glass handling & installations
- Small part stamping
- Wiring

Performance Profile

Superior Cut Protection

INTERCEPT™ Cut Resistance Technology combines a proprietary blend of high performance polyethylene into differentiated engineered yarn for ANSI Level 2 cut protection.

Extended Wear Life

Polyurethane coating provides ANSI Level 5 abrasion protection and excellent resistance to tears. Tough coating provides a sure grip in light oil and dry applications. Grey palm color hides soil.

All Day Comfort

Glove molds naturally to the hand and is soft and cool to the skin for all day comfort.

Dexterity

The exceptional precision, dexterity and flexibility when handling small, sharp parts increases worker confidence while on the job.

Key Features

INTERCEPT™ Cut Resistance Technology with Ergonomic Design

Enhanced cut protection, wear life and comfort with a high level of dexterity.

Polyurethane Coating

High dexterity with longer wear due to low palm weight and excellent abrasion resistance.

Durable and Launderable

Minimal shrinkage and excellent recovery after laundering extends glove life for reduced total cost of ownership.

Sizing

Available in a broad range of sizes to fit all workers from 5-12.



Performance Standards



4342
EN 388

CUT

Featured Technologies



INTERCEPT™
Cut Resistance Technology

Specifications

STYLE	DESCRIPTION	GAUGE	LENGTH	COLOR	PACKAGE
11-644	<p>Type: palm dipped</p> <p>Coating material: silicon-free polyurethane</p> <p>Liner material: Seamless Plaited Synthetic blend with INTERCEPT™ Technology yarn</p> <p>Cuff style: knit wrist</p>	13	220-270 mm	Grey coating on white liner	12 pairs/bag, 12 bags/carton

* & ™ are trademarks owned by Ansell Limited or one of its affiliates, © 2015 Ansell Limited. All Rights Reserved.

Neither this document nor any other statement made herein by or on behalf of Ansell should be construed as a warranty of merchantability or that any Ansell product is fit for a particular purpose. Ansell assumes no responsibility for the suitability or adequacy of an end user's selection of gloves for a specific application.

Europe
Ansell Healthcare Europe NV
Riverside Business Park
Blvd International, 55
1070 Brussels, Belgium
+32 2 528 74 00
+32 2 528 74 01

United States
Ansell Protective Products Inc.
111 Wood Avenue South
Suite 210
Iselin, NJ 08830, USA
+1 800 800 0444
+1 800 800 0445

Australia
Ansell Limited
Level 3, 678 Victoria Street,
Richmond, Vic, 3121
Australia
+61 1800 337 041
+61 1800 803 578

Hong Kong
Ansell (Hong Kong) Limited
Unit 3102-3103, 31/F
Manhattan Place
23 Wang Tai Road
Kowloon Bay, Hong Kong
+852 2185 0600
+852 2856 2155

Latin America
Ansell Brazil Ltda.
Rua das Figueiras, 474 - 4º Andar
Bairro Jardim
SP 09080-300 Santo André
Brazil
CNPJ: 03.496.778/0001-21
+55 11 3356 3100

Russia
Анселл РУС
123610 Россия, Москва
Краснопресненская
Наб. 12, п.3, оф. 1304А
Тел. +7 495 258 13 16