



# GoatThroat® Pumps

**Safety By Design**  
**Engineered for Life**

## Why Use GoatThroat Systems?

**Safe:** Eliminate hazards: spills, drips, vapors, and VOCs; stop tipping containers; light-weight, chemically resistant polypropylene construction with beer-tap style configuration delivers liquids from upright containers with excellent ergonomics; best up to 270 cP, 14,000 SSU, 300 cSt; color coded.

**Simple:** Install pumps on barrels and pails easily; deliver precise, controlled amounts of liquid from drops to gallons; quick switch between containers improves efficiency; a remote tap delivers liquids to point of use; up to 4GPM.

**Save:** 10+ year life expectancy; conserve liquid inventory; reduce wasted time with precise, controlled delivery; RCRA empty barrels - empty to the last 1/2 inch or less; prevent hazardous spills.

**Sustain:** Using larger containers reduces environmental impact of throwing away many smaller containers; pumps can be rebuilt to factory new instead of throwing away into the landfill; controlled delivery of chemicals allows exact measurement of liquids to meet EPA compliance.



Think of these  
**Pumps as PPE**

- NO Spills
- NO Splashing
- NO Fumes
- NO Hazard






**GoatThroat®**  
Worker Safety and Environmental Compliance



# Occupational Health and Safety

## GoatThroat Pumps and Accessories

*Extended life expectancy make these the best value!*

See the savings - compare ownership costs								
ITEM	ISSUE	ISSUE FREQUENCY	USUAL RESOLUTION	ISSUE COST	REPLACEMENT COST \$\$\$	REPLACEMENT COSTS EXPLANATION	3 YEAR COST	TOTAL COST
<b>GOATTHROAT PUMP AND OPTIONAL PNEUMATIC ADAPTER</b>								
	TAP O-RING FAILS	3 YEARS	REPLACEMENT	\$64.00	\$64.00		\$64.00	
						PURCHASE ORDER GENERATION	\$100.00	\$100.00
								<b>3 year cost = \$164.00</b>
<b>ROTARY PUMP</b>								
	TOO MUCH LIQUID DISPENSED	WEEKLY	LABOR TO POUR EXCESS BACK IN DRUM	\$5.00	N/A		\$780.00	
	PRIMING PUMP	EVERY TIME		\$5.00	N/A		\$780.00	
	PUMP FAILS	ANNUAL	REPLACE		\$ 100.00	PURCHASE ORDER GENERATION	\$300.00	
							<b>3 year cost = \$1860.00</b>	
<b>DRUM PUMP</b>								
	TOO MUCH LIQUID DISPENSED	WEEKLY	LABOR TO POUR EXCESS BACK IN DRUM	\$5.00	N/A		\$780.00	
	WORKER'S ROTATOR CUFF HURTS FROM LIFTING LIQUID	ANNUAL	SEND EMPLOYEE TO DOCTOR; REDUCED HOURS	\$ 250.00	N/A		\$750.00	
	PUMP FAILS	6 MONTHS	REPLACE		\$ 100.00	PURCHASE ORDER GENERATION	\$600.00	
							<b>3 year cost = \$2130.00</b>	

\* Cost Chart for Illustration Purposes only

### EPDM



**GT200** Caustics, Soaps  
Food Grade

**SCP200** Flammables

### Viton



**GT300** Acids, solvents  
herbicides, oils with additives

**SCP300** Flammables

### Nitrile



**GT100** - Most oils  
Food Grade

**SCP100** Flammables

### Santoprene



**GT200S** - Acetone, MEK  
Food Grade

**SCP200S** Flammables



**Discharge nozzle**  
delivers fluids  
to point of use



**DQGT - Viton and EPDM**  
DrumQuik® for GoatThroat  
Specialty Drum Adapters  
DrumQuik is a registered trademark of  
Colder Products Company



**Pneumatic adapter**  
delivers electric pump  
performance with only 4psi