



Traverse™

Vented, Industrial Climbing Helmet with Mips® Brain Protection System for Industrial Safety Helmets, ABS Shell, EPS Foam Impact Liner, HDPE Suspension, Wheel Ratchet Adjustment and 4-Point Chin Strap

- Ultra lightweight shell made with ABS material provides superior protection
- Mips® (Multi-directional Impact Protection System) Brain Protection System for Industrial Safety Helmets is a low frictional layer designed to reduce rotational motion transferred to the head from angled impacts
- EPS foam impact liner helps absorb the forces of front, side, or rear impacts
- Includes a 4-point cross-over chin strap with quick release buckle that is adjustable for a safe & secure fit
- Rugged non-slip adjustable SURE-LOCK wheel ratchet ensures proper suspension performance and effortless fit for all head sizes
- Inner suspension includes comfortable padding for above the brow line



Technical Data

Color	Black, Dark Green, Gray, Hi-Vis Yellow, Navy, Orange, Red, White, Yellow
Sizes Available	OS
Packaging	Boxed
Packed	18/Case
Case Dimensions (in)	28.35 x 11.61 x 30.71
Case Weight (lbs)	29.17
Country of Origin	China
Shell Material	ABS
Shell	Vented
Brim Style	Cap Style
Brim Length	Micro
Size Adjustment	Wheel Ratchet
Suspension	Foam Cradle System
Chin Strap	4-Point Polyester
Sweatband	Polyester EVA
Size Range	53cm-63cm
Construction	MIPS Technology
Certifications	EN 12492
Product Circularity	Recycled via Terracycle

Performance Data

ANSI Type	Type II
Electrical Class	Class C

Care Instructions

The unit may be cleaned with soap and warm water and dried with a soft cloth. The helmet should not be cleaned with chemical or abrasive cleaners. The helmet should be stored out of direct sunlight, away from chemicals and not exposed to extremes of temperature.

SKU Information

Thomas No.	Mfr. No	Color	Size	Description
24A00G041	280-HP1491RVM-11	Black Vented	OS	Industrial Climbing Helmet with Mips® Technology, ABS Shell, EPS Foam Impact Liner, HDPE Suspension, Wheel Ratchet Adjustment and 4-Point Chin Strap
24A00G042	280-HP1491RVM-09	Gray Vented	OS	Industrial Climbing Helmet with Mips® Technology, ABS Shell, EPS Foam Impact Liner, HDPE Suspension, Wheel Ratchet Adjustment and 4-Point Chin Strap
24A00G043	280-HP1491RVM-44	Hi-Vis Yellow Vented	OS	Industrial Climbing Helmet with Mips® Technology, ABS Shell, EPS Foam Impact Liner, HDPE Suspension, Wheel Ratchet Adjustment and 4-Point Chin Strap
24A00G044	280-HP1491RVM-08	Navy Vented	OS	Industrial Climbing Helmet with Mips® Technology, ABS Shell, EPS Foam Impact Liner, HDPE Suspension, Wheel Ratchet Adjustment and 4-Point Chin Strap
24A00G045	280-HP1491RVM-03	Orange Vented	OS	Industrial Climbing Helmet with Mips® Technology, ABS Shell, EPS Foam Impact Liner, HDPE Suspension, Wheel Ratchet Adjustment and 4-Point Chin Strap
24A00G046	280-HP1491RVM-15	Red Vented	OS	Industrial Climbing Helmet with Mips® Technology, ABS Shell, EPS Foam Impact Liner, HDPE Suspension, Wheel Ratchet Adjustment and 4-Point Chin Strap
24A00G047	280-HP1491RVM-01	White Vented	OS	Industrial Climbing Helmet with Mips® Technology, ABS Shell, EPS Foam Impact Liner, HDPE Suspension, Wheel Ratchet Adjustment and 4-Point Chin Strap
24A00G048	280-HP1491RVM-02	Yellow Vented	OS	Industrial Climbing Helmet with Mips® Technology, ABS Shell, EPS Foam Impact Liner, HDPE Suspension, Wheel Ratchet Adjustment and 4-Point Chin Strap

PROTECTIVE INDUSTRIAL PRODUCTS, INC. | BRINGING THE BEST OF THE WORLD TO YOU®