

Product Datasheet

Product code: ES5152.CR.BG

Product type: High Precision Cutters

Made in: Switzerland

Description: The 5152 is a high precision cutter belonging to the large oval cutter family. This type of geometry provides excellent resistance, while the 5152 head dimensions support the cut. The full-flush cutting edge is suitable to perform very clean cuts on small size material. The 5152 is equipped with an ESD Ergo-tek slim handle which allows an excellent grip, suitable to environments and to components susceptible to electrostatic discharge. The blades are hardened to 67HRC hardness.

Head description: Large Oval

Cutting edges: Full-Flush

Cutting capacity: soft wire 0.2-1.2 mm (32-17 AWG)

Body material: High carbon-chromium low alloy steel (100Cr6)

Handle coating: ESD safe - Thermoplastic Elastomer TPE + Polypropylen compound PP

Picture:



Dimensions:
 OAL 123 mm – 4.843 inch
 Width 60 mm – 2.362 inch
 Height 18 mm – 0.709 inch

