

Micronova® Handles



Micronova **Stainless Steel and Plastic Handles** are designed to work with Micronova mop adapters and cleaning tools. The lightweight handles feature a wide range of fixed length and extendible handle sizes from 8 in. (10 cm) to 277 in. (7 meters).

The handles are more versatile when used with the adjustable angle series of Over Under Handles. Over Under adapters come in 8", 13" and 19" lengths and with the twist knob hinge can be locked at the desired angle.



From top:
Stainless Steel Extension, SSU
Plastic Extension Handle, STAEH
Stainless Steel Fixed Length, SSU
Plastic Fixed Length, STAH

* Different color end caps available for color coding

SPECIFICATIONS

SSU Series Stainless Steel Handles

- Quick Disconnect, snap on mop adapter connection
- Use with all QD series mop frame adapters & cleaning tools
- Use with QP tools with the addition of the SSA-3

STA Series

- ACME threaded end connection for QP series adapters and tools.
- Use with QD tools frames with addition of SSA-2
- Different color end caps available for color coding*

QDAH Handle

- Three lengths to meet cleaning needs, 9, 13 & 19 in. lengths
- Adapter can be set at desired angle for cleaning
- Works with SSU & STA series of handles

SSA Threaded Adapters

- Threaded adapter, SSA-3, connects ACME threaded frames to SSU Series handles.
- SSA-2 threaded adapter connects Micronova quick disconnect mop adapters to ACME threaded handles

Manufactured for use in Controlled Environments

- ISO 5 thru 9 Cleanrooms
- ISO 9001 Certified Manufacturing Facility
- Autoclavable
- Good chemical resistance to disinfectants

Materials of Construction:

SSU Series:

Tube	Electropolished 304 Stainless Steel
Fittings	Polyketone components

STAH and STAEH Series:

Tube	Plastic Coated Fiberglass
Fittings and Grip	Polyketone components

QDAH Series:

Tube	Electropolished 304 Stainless Steel
Angle Joint	Polypropylene

SSA Series:

Tube	Electropolished Stainless Steel
End Cap	Polyketone

Dimensions:

SSU Series Handle Lengths:

Fixed:	8 in. to 61 in. (20.3 cm to 154.9 cm)
Extendable:	14 in to 120 in (35.5cm to 304.8 cm)

STAH and STAEH Series Handle Lengths:

Fixed:	12 in. to 60 in. (30 cm to 150 cm)
Extendable:	18 to 36 in (45.72 to 91.44 cm)
	40 to 72 in (101.6 to 182.88 cm)
	78 to 277 in (198.12 to 703.58 cm)

QDAH Series:

Connection Lengths	8 in. (20 cm), 13 in. (33 cm), 19 in. (48 cm)
--------------------	--

SSA Series:

Lengths	SSA-2: 8 in. (20 cm) SSA-3: 6 in. (15 cm)
---------	--



Micronova Manufacturing, Inc.
3431 W. Lomita Boulevard
Torrance, CA 90505-5010 USA

Tel: 310/784-6990
Fax: 310/784-6980

SalesInfo@micronova-mfg.com
www.micronova-mfg.com