



# ENVIRONMENTALLY RESPONSIBLE RTU Glass & Hard Surface Cleaner

## DESCRIPTION

The EARTH SENSE® Cleaning Product System is a comprehensive program of sanitary maintenance products designed to provide healthy cleaning with a positive environmental profile. EARTH SENSE products solve problems for facility managers with labor-saving, performance-driven formulations. Earth Sense® RTU Glass & Hard Surface Cleaner is an exceptional Glass & Hard Surface Cleaner that cleans without streaks and smears. It can be used on any hard surface, as well as on chrome, stainless steel, mirrors and porcelain.

## PRODUCT FEATURES / BENEFITS

- Ready to Use / No mixing, no diluting. Delivers optimum cleaning performance.
- Does not contain other environmentally harmful alcohols, surfactants or preservatives / safer for the environment and improves indoor air quality.
- Blue color / Window cleaners are universally recognized as blue. Uses an FDA approved food grade dye.

## DIRECTIONS FOR USE

Use this product full strength from this container. No dilution is required. If using this product in a trigger spray bottle, ensure that the bottle is labeled properly.

**For cleaning glass, windows, mirrors, hard surfaces, Plexiglas, porcelain and ceramic tile surfaces:**

Spray RTU Glass and Window Cleaner onto a microfiber cleaning cloth or paper towel (environmentally preferable). Wipe the surface with the cloth or paper towel to loosen smears, finger prints, soil and film. Complete the cleaning by wiping the surface dry using a clean, dry cloth or paper towel.

## SPECIFICATIONS

Color ..... Light blue  
 Dye ..... FDA Approved  
 Odor ..... None  
 pH ..... 10.5 ± 0.4  
 Freeze Stable ..... Yes  
 Flammable ..... No  
 Phosphates ..... No

Corrosive to steel ..... No  
 Corrosive to aluminum ..... No  
 Effect on paints ..... None  
 Effect on caulking ..... None  
 Viscosity (cps) ..... < 10  
 Specific Gravity (g/cc) ..... 1.00 ± 0.01  
 Density (lbs/gal) ..... 8.3 ± 0.1  
 Cleaning ..... Excellent

## ENVIRONMENTAL RECOGNITIONS



The EARTH SENSE® Seal of Assurance is self-certified by NCL, and identifies our products that are formulated to promote human health and worker safety with a preferred environmental profile.



ENVIRONMENTAL PROFILE		
<b>Chemical Ingredients:</b>	<b>Environmental Impact:</b>	<b>Human Toxicity:</b>
Phosphates: .....None	Harmful to water systems:.....No	Skin Corrosive:.....No
Ammonia:.....None	Biodegradable:.....Readily	Eye Corrosive:.....No
Butyl: .....None	VOC Compliant:..... Yes	Skin Sensitizer:.....No
Alcohols: .....None	Recyclable Container: ..... Yes	Eye Sensitizer: .....No
APE/NPE: .....None	Bio-Renewable Resources: . Yes	Skin Irritant:.....No
Dyes: .....FDA Approved	Reactive: .....No	Eye Irritant: .....No
Added Fragrances: .....None	Flammable: .....No	Low Toxicity ..... Yes
Silicates: .....None	Combustible: .....No	Non-Toxic (LD-50):.....No
Chelating Agents: .....None		
Free Alkali: .....None		

**PPE Information:** Respiratory protection is not required. Special ventilation is not required. The use safety glasses is recommended. No other protective equipment is required.



401 N. 10th Street • Philadelphia, PA 19123  
 1-800-NAT-CHEM • 215-922-1200 • FAX: 215-922-5517  
 www.nclonline.com • e-mail:info@nclonline.com